

Connection Procedure

1. Put on mask.
2. Wash hands. Dry thoroughly.
3. Uncoil Y-set tubing.
4. Place drain bag on the floor.
5. Place a blue clamp on the new bag line.
6. Break the green cone.
7. Break the blue cone.
8. Check that the clamp on the transfer set is closed.
9. Pull off colored pull ring tab from Y set.
10. Remove disconnect cap from the end of the transfer set.
11. Connect the Y set tubing to the transfer set.
12. Remove mask.

Disconnect Procedure

1. Put on mask.
2. Wash hands. Dry thoroughly.
3. Open the disconnect cap package.
4. Disconnect the Y set from the transfer set.
5. Screw the new cap onto the transfer set.
6. Remove mask.